

CIRCULAR CUTTERS “DISC series”

(manual operate rotary)

For cutting samples in circular shape of Paper, Corrugated Board*, Aluminum Foil, Films...



**To cut Corrugated Board of a Thickness up to 5 mm maximum*

The cutting is done by placing the samples on a porous rubber plate included in the standard supply and applying the sample cutter on top of the cardboard board to be cut, its knob is rotated by pressing it downwards at the same time. One turn of the knob is enough so that the final sample is cut impeccably.

The change of the blades is carried out by the side neck of the device.

The lowering movement of the blades is always blocked by a device located next to the neckline. Pulling the small knurled cylinder out and giving it a quarter turn, the movement is free for cutting.

Standard versions:

- DISC-100 model (samples of 100 cm²)
- DISC-50 model (samples of 50 cm²)
- DISC-25 model (samples of 25 cm²)
- DISC-10 model (samples of 10 cm²)

Special versions:

- DISC-64 model (samples of 10 in²)
- DISC-32 model (samples of 5 in²)

Spare parts:

- DISC Series Spare Set: Includes 5 rubber plates and 100 replacement blades